


# OPERATING INSTRUCTIONS

## DM-2000/DM-2001

### DIGITAL MULTIMETER

### WITH AC/DC CLAMP SENSOR



**PLEASE READ THESE OPERATING INSTRUCTIONS CAREFULLY**  
Misuse and or abuse of these instruments cannot be prevented by any printed word and may cause injury and/or equipment damage. Please follow all these instructions and measurement procedures faithfully and adhere to all standard industry safety rules and practices.

## **A.W. SPERRY INSTRUMENTS, INC.**

245 MARCUS BLVD., HAUPPAUGE, NEW YORK 11788  
Phone: 800-645-5398 Toll Free (N.Y. and Alaska call collect 631-231-7050)  
Fax: 631-434-3128


## 1. SAFETY WARNINGS

This instrument has been designed and tested according to IEC Publication 61010: Safety Requirements for Electronic Measuring Apparatus. This instruction manual contains warnings and safety rules which must be observed by the user to ensure safe operation of the instrument and to retain it in safe condition. Therefore, read through these operating instructions before starting using the instrument.

### **WARNING**

- Read through and understand instructions contained in this manual before starting to use the instrument.
- Save and keep the manual handy to enable quick reference whenever necessary.
- Be sure to use the instrument only in its intended applications and to follow measurement procedures described in the manual.
- Be sure to understand and follow all safety instructions contained in the manual.

Failure to follow the above instructions may cause injury, damage to the instrument and/or damage to equipment under test.

The symbol  indicated on the instrument means that the user must refer to related parts of the manual for safe operation of the instrument. Be sure to carefully read the instructions following each symbol in this manual.

- △ **DANGER** is reserved for conditions and actions that are likely to cause serious or fatal injury.
- △ **WARNING** is reserved for conditions and actions that can cause serious or fatal injury.
- △ **CAUTION** is reserved for conditions and actions that can cause minor injury or instrument damage.

### **DANGER**

- Never make measurement on circuits with a maximum voltage difference of 600VAC/DC or greater between conductors (300VAC/DC or greater between a conductor and ground).
- Do not attempt to make measurement in the presence of flammable gasses. Otherwise, the use of the instrument may cause sparking, which leads to an explosion.
- Never attempt to use the instrument if its surface or your hand is wet.
- Do not exceed the maximum allowable input of measuring ranges.
- Never open the battery compartment cover while making measurement.

### **WARNING**

- Never attempt to make any measurement, if any abnormal conditions are noted, such as broken case, cracked test leads and exposed metal parts.
- Do not turn the Function Selector Switch while the test leads are connected to the circuit under test.
- Do not install substitute parts or make any modification to the instrument. Return the instrument to Sperry for repair or re-calibration.
- Do not try to replace the batteries if the surface of the instrument is wet.
- Always disconnect the clamp sensor and the test leads from the circuit under test and switch off the instrument before opening the battery compartment cover for battery replacement.

### **CAUTION**

- Make sure that the Function Selector Switch is set to an appropriate position before making measurement.
- Always make sure to place the test leads in the test lead holder before making current measurement.
- Do not expose the instrument to the direct sun, extreme temperatures or dew fall.
- Be sure to set the Function Selector Switch to the "OFF" position after use. When the instrument will not be used for a long period of time, place it in storage after removing the batteries.
- Use a damp cloth and detergent for cleaning the instrument. Do not use abrasives or solvents.

## 2. FEATURES

- Permits AC/DC current measurement up to 60A using a clamp sensor that comes standard with the instrument
- Open Jaw Current Clamp Sensor for ease of use in crowded cable areas and other tight places
- Auto-power-save function
- Continuity Buzzer
- Data hold function to freeze the readings
- LCD with a 3400 count full scale bar graph
- Shock absorbing holster allows easy lead storage
- Designed to international safety standard IEC61010-1: over-voltage category CAT.III, 300V and pollution degree 2.
- UL listed to both US and Canadian Standards
- Limited One Year Warranty

## 3. SPECIFICATIONS

- Measuring Ranges and Accuracy (at 23°C ± 5°C, relative humidity 75% or less)

AC Current  $\sqrt{\text{A}}$

MODEL	Range	Measuring Range	Accuracy
2000	60A	0-60.0A	2.0%rdg ± 5dgt(50/60Hz)
2001	100A	0-100.0A	2.0%rdg ± 5dgt(50/60Hz)

DC Current  $\overline{\text{A}}$

MODEL	Range	Measuring Range	Accuracy
2000	60A	0-±60.0A	2.0%rdg ± 5dgt(50/60Hz)
2001	100A	0-±100.0A	2.0%rdg ± 5dgt(50/60Hz)

AC Voltage  $\sqrt{\text{V}}$  Input impedance: 10M

Range	Measuring Range	Accuracy
3.4V	0-600V (Auto ranging)	±1.5rdg±5dgt(50-400Hz)
34V		
340V		
600V		

DC Voltage  $\overline{\text{V}}$  Input impedance: 10M  $\Omega$

Range	Measuring Range	Accuracy
340mV	0-600V (Auto ranging)	±1.5rdg±4dgt
3.4V		
34V		
340V		
600V		

Resistance  $\Omega / \overline{\Omega}$

Range	Measuring Range	Accuracy
340 $\Omega$	Measuring Range 0-33.99M $\Omega$ (Auto-ranging)	±1.0%rdg±3dgt Buzzer beeps below 30±10 $\Omega$ (Continuity buzzer works on 340 $\Omega$ range only)
3.4k $\Omega$		
34k $\Omega$		±5%rdg±5dgt
340k $\Omega$		±15%rdg±5dgt
3.4M $\Omega$		
24M $\Omega$		



Frequency Hz

Range	Measuring Range	Accuracy
Current	0-3.399kHz / 3.4kHz-10kHz (Auto-ranging)	±0.1%rdg±1dgt
Voltage	0-3.399kHz / 3.4kHz-33.99kHz/34kHz-300kHz (Auto-ranging)	±0.1%rdg±1dgt


※ Electromagnetic compatibility (IEC 61000-4-3) RF field ≤ 1 V/m ACV/DCV/OHMS/FREQUENCY total accuracy = specified accuracy ACA/DCA total accuracy = specified accuracy+5dgt RF transmitters such as mobile telephones may not be used in close proximity. Altitude 2000M

• Safety Standard	IEC 61010-1 over-voltage category CAT. II , 300V, pollution degree 2 over-voltage category CAT. III , 600V, pollution degree 2 IEC 61010-2-031 IEC 61010-2-032 IEC 61326 (EMC)
• Operating System	Dual integration
• Display	Liquid crystal display with maximum reading of 3399 as well as units and annunciators Bar graph with maximum points of 33
• Over Input Indication	“OL” on the LCD ( $\Omega$ ranges only)
• Auto-ranging Operation	Shifts to the next higher range when bar graph increases to 33 points Shifts to the next lower range when bar graph decreases to 3 points
• Sample Rate	Numeric reading: about 400ms, bar graph: about 20ms
• Accuracy-insured Temperature and Humidity Ranges	23°C $\pm$ 5°C relative humidity 75% or less (without condensation)
• Operating Temperature and Humidity Range	0-40°C, relative humidity 85% or less (without condensation)
• Storage Temperature and Humidity Range	-20-60°C, relative humidity 85% or less (without condensation)
• Source	Two 1.5VDC R03 (UM-4) “AAA” batteries
• Current Consumption	Approx. 10mA
• Power-save Function	Shifts to the power-save state about 10 minutes after the last switch operation (current consumption: approx. 10 $\mu$ A)
• Overload Protection	AC/DC current ranges: MODEL2000 AC/DC 72A for 10 seconds AC/DC current ranges: MODEL2001 AC/DC 120A for 10 seconds AC/DC voltage ranges: AC/DC 720V for 10 seconds Resistance ranges: AC/DC 720V for 10 seconds Frequency ranges: AC/DC 720V for 10 seconds
• Withstand Voltage	AC3700V for 1 minute between electrical circuit and housing case
• Insulation Resistance	10M $\Omega$ or greater at 1000V between electrical circuit and housing case
• Conductor Size	MODEL2000 Approx. 6mm diameter max. MODEL2001 Approx. 10mm diameter max.
• Dimensions	MODEL2000 128(L) x 87(W) x 24(D)mm MODEL2001 128(L) x 92(W) x 27(D)mm
• Weight	MODEL2000 Approx. 210g MODEL2001 Approx. 220g
• Accessories	Two R03 (UM-4) “AAA” batteries Instruction Manual

## 4. INSTRUMENT LAYOUT



How to put test lead in.



## 5. PREPARATIONS FOR MEASUREMENT

### (1) Checking battery voltage

Set the Function Selector Switch to any position other than the OFF position. If the marks on the display are clearly legible without symbol 'BATT' showing, battery voltage is OK. If the display blanks or 'BATT' is indicated, replace the batteries according to section 8: Battery Replacement.

## NOTE

When the instrument is left powered on, the auto-power-save function automatically shuts the power off; The display blanks even if the Function Selector Switch is set to a position other than the OFF position in this state. To power on the instrument, turn the Function Selector Switch or press the Data Hold Button. If the display is still blank, the batteries are exhausted. Replace the batteries.

- (2) Make sure that the Function Selector Switch is set to the appropriate range.

Also make sure that data hold function is not enabled. If inappropriate range is selected, desired measurement cannot be made.

- (3) Install Test Lead to the Holster on the side of body

It is now possible to measure with seeing the LCD Display. Keep Test Lead installed in the Holster.



## 6. HOW TO MAKE MEASUREMENT




### 6-1 Current Measurement

#### DANGER

- In order to avoid possible shock hazard, never make measurement on circuits with a maximum voltage difference of 600VAC/DC or greater between conductors (300VAC/DC or greater between a conductor and ground).
- Do not make measurement with the test leads connected to the circuit under test. Never make measurement with the battery compartment cover removed.

#### CAUTION

- When handling the clamp sensor, exercise caution not to apply excessive shocks or vibration to the sensor.
- Maximum measurable conductor size is MODEL2000 6mm / MODEL2001 10mm in diameter.



#### 6-1-1 DC Current Measurement

- (1) Set The Function Selector Switch to the " $\text{mA}$ " position. ("DC" and "AUTO" marks are shown on the top of the display.)
- (2) Turn the 0 (Zero) ADJ knob to set the reading of the multimeter to zero. (If this zero adjustment is made incorrectly, measurement errors will result.)
- (3) Adjust one of the conductors to the center of the clamp sensor's arrow. (When the position of the conductor is not at the center of the arrow, an error may occur)

Measured value is shown on the display.

Note: When current flows from the upside to the underside of the instrument, the polarity of the reading is positive (+). Otherwise, the polarity of the reading is negative (-).

### 6-1-2 AC Current Measurement

- (1) Set the Function Selector Switch to “  $\sim$  A.”  
 (“AC” and “AUTO” marks are shown on the top of the LCD.)
- (2) Adjust one of the conductors to the center of the clamp sensor's arrow.  
 (When the position of the conductor is not at the center of the arrow, an error may occur.)  
 Measured value is shown on the display.

Note: Unlike DC current measurement, zero adjustment is not necessary. There is not polarity indication either.

### 6-2 Voltage Measurement

 **DANGER**

- In order to avoid possible shock hazard, never make measurement on circuits with a maximum voltage difference of 600VAC/DC or greater between conductors (300VAC/DC or greater between a conductor and ground).
- Do not make measurement with the battery compartment cover removed.

#### 6-2-1 DC Voltage Measurement

- (1) Set the Function Selector Switch to “  $\text{---}$  V.”  
 (“DC” and “AUTO” marks are shown on the top of the LCD.)
- (2) Connect the red test lead to the positive (+) side of the circuit under test and the black test lead to the negative (-) side. Measured voltage value is shown on the display.  
 When the connection is reversed, “-” is shown on the display.

#### 6-2-2 AC Voltage Measurement

- (1) Set the Function Selector Switch to “  $\sim$  V.”  
 (“AC” and “AUTO” marks are shown on the LCD.)
- (2) Connect the test leads to the circuit under test.  
 Measured voltage value is shown on the display.

### 6-3 Resistance Measurement

 **DANGER**

- Never make measurement on circuits that are live.
- Never make measurement with the battery compartment cover removed.

- (1) Set the Function Selector Switch to “  $\Omega$  /  $\text{---}$  .”
- (2) Check that the display shows over-range. Short the test leads and check that the buzzer beeps and the display reads zero.
- (3) Connect the test leads to the circuit under test. Measured resistance value is shown on the display. When the measured value is below about 30  $\Omega$  , the buzzer beeps.

Note: When the test leads are shorted, the display may read a small resistance value.

This is the resistance of the test leads.

If there is an open in either of the test leads, “OL” is shown on the display. On the 340  $\Omega$  range, “  $\text{---}$  ” is shown on the left side of the LCD.

### **DANGER**

- In order to avoid possible shock hazard, never make measurement on circuits with a maximum voltage difference of 600VAC/DC or greater between conductors (300VAC/DC or greater between a conductor and ground).
- Do not make measurement with the test leads connected to the circuit under test. Never make measurement with the battery compartment cover removed.
- Do not make current measurement with the test leads connected to the circuit under test.

(1) Set the Function Selector Switch to "Hz."

(2) Measuring frequency of current:

Adjust one of the conductors to the center of the clamp sensor's arrow.

Measured value is shown on the display.


Measuring frequency of voltage:

Connect the test leads to the circuit under test. Measured frequency is shown on the display.

**Note:** Measuring range of current frequency is 0-10kHz with minimum measurable input of MODEL2000 16A(Typ)/MODEL2001 10A(Typ).

Measuring range of voltage frequency is 0-300kHz with minimum measurable input of 10V(Typ).

When measuring frequency, do not attach the clamp sensor and the test leads to the circuit under test simultaneously.



## 7. OTHER FUNCTIONS

### 7-1 Auto-Power-Save Function

#### **NOTE**

A small amount of current is consumed even in the power-save state. Make sure to set the Function Selector Switch to the OFF position when the instrument is not used.

This function helps to avoid unwanted exhaustion of the batteries and helps extend battery life. The instrument automatically shifts to the power-save state about 10 minutes after the last Function Selector Switch or other switch operation.

To return to the normal state: Turn the Function Selector Switch or press the Data Hold Button twice to exit the power-save state and enable measurement functions.



## 7-2 Data Hold Function

This is a function to freeze a measured value on the display. Press the Data Hold Button once to hold the current reading. In this data hold state, the reading is held even if input varies. "H" and "■" marks are shown on the LCD instead of "AUTO" mark.

To exit the data hold state, press the Data Hold Button again.

## 7-3 Range Hold Function

The instrument defaults to auto-ranging ("AUTO" is shown on the LCD).

Pressing the Range Hold Button enables manual selection among measurement ranges (■ mark is shown on the LCD instead of "AUTO" mark)

Press the Range Hold Button to select a higher range.

To switch from manual range selection to auto-ranging, press down the Range Hold Button for about one seconds, or turn the Function Selector Switch to another position before setting it back to the current range.

## 8. BATTERY REPLACEMENT

### WARNING


- In order to avoid possible shock hazard, always disconnect the test leads from the circuit under test and set the Function Selector Switch to the OFF position before trying to replace the batteries.

### CAUTION

- Do not mix new and old batteries.
- Install batteries in the orientation as shown inside the battery compartment, observing correct polarity.

When the battery voltage warning mark "BATT" is shown on the top left corner of the LCD, replace the batteries. Note that the display blanks and "BATT" mark is not shown if the batteries are completely exhausted.

- (1) Set the Function Selector Switch to "OFF."
- (2) Remove the instrument from the holster.
- (3) Loosen the battery-compartment-cover-fixing screw on the lower back of the instrument.
- (4) Replace the batteries with two new R03 (UM-4) "AAA" 1.5V batteries.
- (5) Put the battery compartment cover back in place and tighten the screw.



## **LIMITED WARRANTY**

A.W. Sperry Instruments warrants that this A.W. Sperry Instrument has been carefully tested, inspected, and warranted for one year from the date of purchase by the original end user, provided the instrument has not been misused, damaged due to negligence, neglect or unauthorized repair, abused or used contrary to the operating instructions. Instruments and proof of purchase in the form of a legible copy or original of the sales receipt clearly identifying the distributor, model number and date of purchase must be returned to A.W. Sperry Instruments Inc., Attention: Customer Service Center, 245 Marcus Blvd., Hauppauge, NY 11788, postage prepaid for examination and verification of manufacturing defect under warranty. A.W. Sperry shall be the sole judge of such defect. The liability of A.W. Sperry Instruments, Inc. shall be limited to the repair or replacement at its sole option of any defective product.

## **A.W. SPERRY INSTRUMENTS, INC.**

245 MARCUS BLVD., HAUPPAUGE, NEW YORK 11788

Phone: 800-645-5398 Toll Free (N.Y. and Alaska call collect 631-231-7050)

Fax: 631-434-3128